



**Cat. Nos. 0805, 0834, 0835 Series Sea Cocks
Cat. No. 0825 Series In-Line Valves**

IMPORTANT INFORMATION

For proper installation, A.B.Y.C. Standard H-27 (Sea Cock, Thru-Hull Connections, etc.) must be adhered to.

For proper protection, A.B.Y.C. Standards E-1 (Bonding of direct current systems) and E-2 (Cathodic protection) must be adhered to.

The above referenced standards can be obtained from:

American Boat & Yacht Council, Inc.
3069 Solomon's Island Road
Edgewater, Maryland 21037

MAINTENANCE:

- Lubrication - Periodically lubricate handle stem with waterproof pump grease in order to reduce stiffness. Ball and seats are self-lubricating, however, inspect for deposits and foreign matter.
- Winterizing - Sea Cocks have two drain plugs (In-Line valves have one) for draining water from the device prior to freezing conditions.

SPARE PARTS:

<u>Size No.</u>	<u>Pipe to Hose Size Inches</u>	<u>Thru-Hull Connections</u>	<u>Straight Hose Adapters</u>	<u>90° Hose Adapters</u>	<u>Packing Kits (Seacocks only)</u>
4	1/2 to 5/8	N/Recom.	0076004PLB	N/A	N/A
5	3/4 to 3/4	0322005PLB	0076005PLB	0063005PLB	080500599A
6	1 to 1	0322006PLB	0076006PLB	0063006PLB	080500699A
7	1-1/4 to 1-1/4	0322007PLB	0076007PLB	0063007PLB	080500799A
8	1-1/2 to 1-1/2	0322008PLB	0076008PLB	0063008PLB	080500899A
9	2 to 2	0322009PLB	0076009PLB	0063009PLB	080500999A
10	2-1/2 to 2-1/2	0322010PLB	0076010PLB	0063010PLB	080501099A
11	3 to 3	0322011PLB	0076011PLB	0063011PLB	080501199A

9/05
0805INS1

PERKO, INC.
16490 N.W. 13th Avenue
Miami, FL 33169-5707
www.perko.com