


# Care and Use: Magma Padded Grill and Accessories Carrying / Storage Case

## SAFETY:


- Always store in a well ventilated area.
- Never store carrying case with propane canisters in unventilated areas or below deck on a boat.
- Never store hot grill in case.
- Use caution when storing items with sharp points and edges (knives, forks, other utensils, and grill edges)
- Disconnect control valve regulator from fuel canister prior to storage.

## ASSEMBLY / INSTALLATION INSTRUCTIONS:


- Before using install propane cylinder storage compartment. See figure 1



- Velcro compartment separator in place
- Grill, Fuel Canisters, and Control/Valve Regulators are stored in the main compartment while Griddle, Fish and Veggie Tray, and Serving Shelf are stored in external compartment. See figure 2
- Always store grill with handle facing up, for easy installation and removal
- Always store grill with base and mount facing protective plastic panel. See A in figure 2




- Grills with a Levellock rod holder mount in the front to back position must be stored with the tube assembly in the upwards position. **Note: to secure close both zippers from each side to come together in the center of the case, when stored in this position the mount tube will extend outside of case.** See figure 3



- Grills with a levellock rod holder mount in the side to side position must be stored with the tube assembly placed to the canister side of the carrying case.

See figure 4



## USE:

- Insure that all internal grill components (grill grates, radiant plate, and warming rack) are properly secured prior to storage or transportation.
- Always remove control valve/regulator or low pressure control valve from grill prior to storing or transporting.
- Store control valve/regulator and fuel canisters in appropriate internal compartment.
- Damage sustained from sun exposure and general weather related damages sustained from outside storage is not covered under product warranty.
- Protect items with a Non-Stick surface while being transported and/or stored to prevent scratching or surface damage.

## CLEANING:

- Hand wash with cold water a mild dishwashing detergent and thoroughly air dry.
- Never use any abrasive cleansers, cleaners, and/or cleaning products on this product.

## WARRANTY:

- Magma Products, Inc. warrants this product to be free of defects in materials and/or workmanship for a period of 1 year from the date of original purchase (proof of purchase required).
- Magma Products, Inc. will not be liable for products damaged due to outside storage; discoloration from sun exposure, any weather related damages, general neglect, and/or misuse by the user.
- Magma Products, Inc. must inspect and approve all product warranty claims.
- Magma Products, Inc. reserves the exclusive right to repair and/or replace any defective, damaged, or non-working products and/or product components.
- Warranty claims; Do Not contact or return this product to retailer. Prior to returning product contact Magma Products, Inc. directly for return authorization and instructions.
- Returning warranty claims; user is responsible for all applied shipping charges.

# MAGMA®

Magma Products, Inc. • 3940 Pixie Ave. • Lakewood, CA 90712 • USA • Tel: (562) 627-0500  
www.MagmaProducts.com • e-mail: mail@MagmaProducts.com