ComNav






1001 Autopilot

Advanced Technology for Accurate Steering Simple to Operate

- Fixed station autopilot
- Suitable for mid-sized vessels, in the range of 30 to 60 feet / 10 to 20 meters
- Three "Turn" functions, Continuous, Emergency and "U" Turns
- Compatible with most standard types of steering systems
- Water resistant Control Head
- Automatic trim
- Adjustable yaw, turn rate and rudder settings
- Easy course changes, from one degree to major changes
- "Nav" mode accepts NMEA 0183 information
- Fast and Slow Modes may be automatically implemented by Nav device
- Ten selectable steering parameters for both Fast and Slow Modes
- Digital display of rudder angle
- Output for optional analog rudder angle indicator, up to 4 stations
- · Backlit LCD display for comfortable viewing
- · Adjustable brightness and contrast
- Built-in diagnostics and self tests plus visual and audible alarms
- Easy to install and fully compatible with your onboard instruments
- Extended 3 year warranty
- Meets CE requirements
- · Reliable in any sea and weather conditions

1001 Autopilot



A basic ComNav 1001 electronics package includes: Control Unit, Distribution Box, Fluxgate Compass or Standard Sensor for a Magnetic Compass, output for Solenoid Valves, Rotary or Linear Feedback and Interconnecting Cables.

Rudder Angle Indicator

Optional Solenoid or Motor Drive Controller

ComNav 1001 Automatic Pilot Specifications

Operating Voltage: 12 or 24V DC

Power Consumption: Average 0.5 amps, 3 amps Peak

Solenoid Output: 3 amps max.

Navigational Interface: NMEA 0183

Heading Reference: Fluxgate or Magnetic Compass

Course Resolution: 1° Course Detection: 0.25°

Dimensions

Control Unit: 203mm x 83mm x 92mm / 8.0 x 3.26 x 3.6 inches Distribution Box: 114mm x 133mm x 25mm / 4.6 x 5.25 x 1.0 inches Fluxgate Compass: $142mm \times 107mm \times 76mm / 5.6 \times 4.2 \times 3.0$ inches

Options

A wide range of fixed or portable full function Remotes.

Non Follow-up Jog Switches.

Remote Expander used to support up to 4 Remotes. Rudder Angle Indicator, easy-to-read analog display.

Rate Stabilized Fluxgate Compass.

Motor Drive Controller to interface with pumps or mechanical drives.

ComNav®

ISO 9001



ComNav Marine Ltd.

#15-13511 Crestwood Place,

Richmond, British Columbia • Canada • V6V 2G1

Phone: 604-207-1600 • Fax: 604-207-8008

E-mail: sales@comnav.com

WWW.COMNav.com

Worldwide Service

Printed in Canada

Represented	by

Specifications subject to change without notice